

Installation and Operations Manual

Enphase Microinverter Model D380-72-2LL



Contact Information

Enphase Energy Inc.
201 1st Street
Petaluma, CA 94952
Phone: 707-763-4784 Toll Free: 877-797-4743
Fax: 707-763-0784

<http://www.enphaseenergy.com>

info@enphaseenergy.com

FCC Compliance

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Changes or modifications not expressly approved by the party responsible for compliance may void the user's authority to operate the equipment.

Other Information

Product information is subject to change without notice. All trademarks are recognized as the property of their respective owners.

For Enphase Envoy Warranty Terms and Conditions, see the Appendix on page 23 of this manual.

Copyright © 2011 Enphase Energy. All rights reserved.



Table of Contents

Important Safety Information	4
Read this First	4
Safety Instructions	4
The Enphase Microinverter System	5
How the D380 Microinverter Works.....	6
System Monitoring	6
Optimal Reliability	6
Enphase Enclosure Formats	7
D380 Planning Considerations.....	7
Enphase D380 Installation.....	9
Parts and Tools Required.....	9
Lightning Surge Suppression	9
Installation Procedure	10
Step 1 - Install the AC Branch Circuit Junction Box.....	11
Step 2 - Attach the Enphase Microinverters to the Racking	12
Step 3 - Install the AC Trunk Cabling	12
Step 4 - Ground the System	13
Step 5 - Complete the Installation Map and Connect the PV Modules.....	14
Complete the Enphase Map	14
Alternative: Create Your Own Map.....	14
Connect the PV Modules.....	14
Step 6 - Build the Virtual Array.....	15
Commissioning	16
Operating Instructions	16
Troubleshooting	17
Status LED Indications and Error Reporting	17
Startup LED Operation:.....	17
GFDI Fault:	17
Other Faults:	17
Troubleshooting an Inoperable Microinverter	18
Disconnecting a Microinverter from the PV Module.....	18
Installing a Replacement Microinverter.....	19
Technical Data	20
Technical Considerations	20
Technical Specifications	20
Enphase D380 TwinPack Microinverter Operating Parameters	20
Voltage and Frequency Limits for Utility Interaction	22
Appendix.....	23
Limited Warranty	23
Enphase Installation Map	25
Sample Wiring Diagram - D380, 240 Vac	26
Sample Wiring Diagram - D380, 208 Vac	27

Important Safety Information

Read this First

This manual contains important instructions to follow during installation and maintenance of the Enphase Microinverter.

To reduce the risk of electrical shock, and to ensure the safe installation and operation of the Enphase Microinverter, the following safety symbols appear throughout this document to indicate dangerous conditions and important safety instructions.



WARNING! This indicates a situation where failure to follow instructions may be a safety hazard or cause equipment malfunction. Use extreme caution and follow instructions carefully.



NOTE: This indicates information particularly important for optimal system operation. Follow instructions closely.

Safety Instructions



WARNING: Be aware that the body of the Enphase Microinverter is the heat sink and can reach a temperature of 80°C under extreme conditions. To reduce risk of burns, do not touch.

- Perform all electrical installations in accordance with all local electrical codes and the National Electrical Code (NEC), ANSI/NFPA 70.
- Be aware that only qualified personnel should install and/or replace Enphase Microinverters.
- Do not attempt to repair the Enphase Microinverter; it contains no user-serviceable parts. If it fails, please contact Enphase customer service to obtain an RMA number and start the replacement process. Tampering with or opening the Enphase Microinverter will void the warranty.
- Before installing or using the Enphase Microinverter, please read all instructions and cautionary markings in the technical description and on the Enphase Microinverter system and the PV-array.
- Connect the Enphase Microinverter to the electrical utility grid only after receiving prior approval from the utility company.
- Do NOT disconnect the PV module from the Enphase Microinverter without first removing AC power.

The Enphase Microinverter System

The Enphase Microinverter System is the world's most technologically advanced inverter system for use in utility-interactive applications. This manual details the safe installation and operation of the Enphase Microinverter.

The three key elements of an Enphase Microinverter System are:

- the Enphase Microinverter
- the Enphase Envoy™ Communications Gateway
- the Enphase Enlighten™ web-based monitoring and analysis system

This integrated system maximizes energy harvest, increases system reliability, and simplifies design, installation and management.



- 1 **Enphase Microinverter System**
 - installed on the racking beneath each solar module
 - maximizes energy harvest
- 2 **AC power travels over AC wiring to the load center**
 - performance data is also sent via the AC wiring
 - plug and play communications
- 3 **Envoy Communications Gateway**
 - plugs into any AC outlet
 - collects information via the AC wiring
 - transmits data through a standard ethernet router to the internet
- 4 **Standard Ethernet Router**
 - information collected by the Enphase Envoy is then transmitted to Enlighten in 5-minute intervals
- 5 **Enphase Enlighten Monitoring**
 - provides monitoring and analysis
 - performance information can be viewed from any web browser



How the D380 Microinverter Works

The Enphase Microinverter maximizes energy production from your photovoltaic (PV) array. Each Enphase D380 houses two microinverters and is individually connected to two PV modules in your array. This unique configuration means that an individual Maximum Peak Power Point Tracker (MPPT) controls each PV module. This insures that the maximum power available from each PV module is exported to the utility grid regardless of the performance of the other PV modules in the array. That is, although individual PV modules in the array may be affected by shading, soiling, orientation, or module mismatch, the Enphase Microinverter insures top performance for its associated PV module. The result is maximum energy production from your PV system.

System Monitoring

Indoors, you can install the Envoy Communications Gateway by plugging it into any convenient 120Vac wall socket and providing an Ethernet connection to your broadband router or modem. After installation of the Envoy, the full network of Enphase Microinverters automatically begins reporting to the Enphase Enlighten web server. The Enlighten software presents current and historical system performance trends, and it informs you when the PV system is not performing as expected.

Optimal Reliability

Microinverter systems are also inherently more reliable than centralized or string inverters. The distributed nature of a microinverter system ensures that there is no single point of system failure in the PV system. Enphase Microinverters are designed to operate at full power at ambient temperatures as high as 65°C (150°F). The inverter housing is designed for outdoor installation and complies with the NEMA6 environmental enclosure rating standard:

NEMA6 rating definition: Indoor or outdoor use primarily to provide a degree of protection against hose-directed water, and the entry of water during occasional temporary submersion at a limited depth, and damage from external ice formation.

Ease of Design


PV systems using Enphase Microinverters are very simple to design and install. You will not need string calculations, and you can install individual PV modules in any combination of module quantity, type, age and orientation. You won't need to install cumbersome centralized or string inverters. Each microinverter quickly mounts on the PV racking, directly beneath each PV module. Low voltage DC wires connect from the PV module directly to the co-located microinverter, eliminating the risk of personnel exposure to lethal 600Vdc power.

Enphase Enclosure Formats


Enphase Microinverters are available in two enclosure designs:

- The M190 and M210 single microinverter enclosures contain one DC input section and one AC output cable per enclosure. The integral AC cable of the single enclosure connects to the adjacent microinverter to create a continuous branch circuit.
- The “TwinPack” (D380) Microinverter enclosure contains two DC input sections and a single AC output connector. There is no integral AC cable on the TwinPack Microinverter enclosure; the AC connection is accomplished with a separate AC trunk cable assembly as shown in the diagram below.

This manual describes the installation and operation of the D380 TwinPack enclosure model.



M190 Single Enclosure Connections



D380 TwinPack Enclosure Connections

D380 Planning Considerations

The Enphase D380 Microinverters are **electrically** compatible with most 60 and 72-cell PV module configurations. They can be used with 240 VAC single phase service or with 208 VAC service. Different trunk cables are required depending on this service type. Balanced 208 VAC is accomplished by alternating phases between microinverters.

Refer to the Enphase website (<http://www.enphaseenergy.com/support/downloads>) for a list of **electrically**-compatible PV modules and approved PV module racking systems. To ensure **mechanical** compatibility, be sure to order the correct connector type for both microinverter and PV module from your distributor.

See the Enphase website (<http://www.enphaseenergy.com/support/downloads.cfm>) for a list of approved PV module racking systems.

The following tables summarize **electrical** compatibility, trunk cables, and branch limits.

D380 TwinPack Model Numbers	Works with PV Module Type	Module Connector Type
D380-72-2LL-S12 D380-72-2LL-S12-NA	60 and 72 cell	MC-4 or Amphenol H4 Type 2 Locking
D380-72-2LL-S13 D380-72-2LL-S13-NA	60 and 72 cell	Tyco Solarlok Locking

D380 Trunk Cable Model Numbers	Description
ET3R-G2-06	AC Trunk Cable with Drops for (3) D380 Inverters, 240Vac Only
ET3C-G2-06	AC Trunk Cable with Drops for (3) D380 Inverters, 208Vac Only
ET1RC-G2-06	AC Trunk Cable with Drops for (1) D380 Inverters, 240Vac or 208Vac

**Maximum number of D380s
Per 20 amp
AC branch circuit**

- 10 @ 240V (20 PV modules)
- 15 @ 208V (30 PV modules)

For more specifications, see the Technical Data section on page 20 of this manual.

Enphase D380 Installation

Follow the instructions in this section to install Enphase D380™ Microinverters.



WARNING: Before installing the Enphase Microinverter, read all instructions and cautionary markings in the user manual, on the Enphase Microinverter, and on the photovoltaic array.



WARNING: Perform all electrical installations in accordance with all local electrical codes and the National Electrical Code (NEC), ANSI/NFPA 70.



WARNING: Connect the Enphase Microinverter to the electrical utility grid only after receiving prior approval from the utility company.



WARNING: Be aware that only qualified personnel should connect the Enphase Microinverter to the electrical utility grid.



WARNING: Be aware that installation of this equipment includes risk of electric shock. Normally grounded conductors may be ungrounded and energized when a ground fault is indicated.

Parts and Tools Required

In addition to the D380 Microinverters, PV modules, racking, and associated hardware, you will need the following items.

Enphase equipment:

- One AC interconnect cable per branch
- AC trunk cables (three-drop and/or single drop models), as needed
- End caps, as needed

Other items:

- Junction box
- Continuous grounding conductor, grounding washers
- Number 2 Phillips screwdriver
- Torque wrench, sockets, wrenches for mounting hardware
- Adjustable wrench or open ended wrench (for cord grips)
- Tool for PV module locking connectors
- ¼" flat blade screwdriver for trunk cable latches

Lightning Surge Suppression

In some areas, the statistical frequency of lightning strikes near a PV installation is high enough that lightning protection should be installed as part of an Enphase system. In areas with lightning flashes greater than 8.0 per square mile per year, the following protection device is recommended. It has been tested to ensure that it does not interfere with power line communications. Install per vendor instructions.

Vendor: Citel

Part Number: DS72RS-120

Application: Residential 120/240V Split Phase where N-G bond exists.

See the vendor datasheet for DS70R, (which includes the DS72RS-120) at http://www.citelprotection.com/english/citel_data_sheets/ac_protection/.

Installation Procedure


Installing the Enphase Microinverter System involves several key steps:

1. Measuring service and Installing the AC branch circuit junction box
2. Attaching the Enphase Microinverters to the racking
3. Installing the AC interconnect cable and AC Trunk cables and connecting the Enphase Microinverters to the AC Trunk cables
4. Grounding the system
5. Connecting the PV Modules, and Completing the Enphase Installation map

Each of the detailed installation steps in the following sections is numerically referenced in the installation diagram below.



WARNING: DO NOT connect Enphase Microinverters to the utility grid or energize the AC circuit(s) until you have completed all of the installation procedures as described in the following sections.



Step 1 - Install the AC Branch Circuit Junction Box

- a. Measure service entrance conductors to confirm AC service at the site. Acceptable ranges are shown in the table below:

240 Volt AC Single Phase		208 Volt AC 3 Phase	
L1 to L2	211 to 264 Vac	L1 to L2 to L3	183 to 229 Vac
L1, L2 to neutral	106 to 132 Vac	L1, L2, L3 to neutral	106 to 132 Vac

- b. Install an appropriate junction box at a suitable location on the PV racking system (typically at the end of a row of modules).



WARNING: Use electrical system components approved for wet locations only.

- c. Connect the open wire end of the Enphase AC interconnect cable into the junction box using an appropriate gland or strain relief fitting. The AC interconnect cable requires a strain relief connector with an opening of 0.5 inches in diameter.

Refer to the wiring diagram for your microinverter model. These diagrams are located in the Appendix of this manual.




WARNING: Use care when terminating phase conductors to the junction box. **If you inadvertently terminate a phase-conductor to Neutral at the junction box, you will damage or destroy all D380 units on that branch-circuit.** Pay careful attention to the correct wire terminations.



NOTE: The AC interconnect cable used with the D380 TwinPack Microinverter is a different cable than used with other Enphase microinverters, please be aware of the difference in wire color code.

All wires except ground are sheathed in black and labeled. Line 1 is labeled "1 – Black", Line 2 is labeled "2 – RED", Line 3 is labeled "3 – BLUE" (used only for three phase 208) and Neutral is labeled "4 – ORANGE". Ground is sheathed in green.

240 VOLT AC SPLIT PHASE WIRING	208 VOLT AC THREE PHASE WIRING		PIN DESIGNATION
BLACK - L1	BLACK - L1		PIN A - L1
RED - L2	RED - L2		PIN B - L2
BLUE - UNUSED	BLUE - L3		PIN C - L3
ORANGE - NEUTRAL	ORANGE - NEUTRAL		PIN D - NEUTRAL
GREEN - GROUND	GREEN - GROUND		PIN E - GROUND

Step 2 - Attach the Enphase Microinverters to the Racking



WARNING: Allow a minimum of .75 inches between the top of the roof and the bottom of the microinverter. We also recommend that you allow 1.0 inch between the back of the PV module and the top of the inverter. Mount the microinverter to the module racking so that the ground clamp is accessible. Do not mount the microinverter in a location that allows long-term exposure to direct sunlight.

The D380 Twinpack Microinverter is design to support two PV modules. The microinverter should be located so that, once the two associated PV modules are installed, the DC wires of the modules can reach the microinverter DC input connectors. The AC trunk cable is constructed using a large gauge trunk cable with smaller gauge tap cables located at two modules wide intervals, approximately 66". This tap cable spacing accommodates most array designs with modules mounted in portrait or landscape orientation.

- a. Mount one microinverter under every other module using hardware recommended by the module racking vendor. Since every microinverter is connected to two modules, position the microinverter so that both module DC cables reach the microinverter DC input connectors. Evaluate the location of the microinverter with respect to the PV module junction box or any other obstructions.
- b. If using grounding washers (e.g., WEEB) to ground the microinverter chassis to the PV module racking, choose a grounding washer that is approved for the racking manufacturer. Install a minimum of one grounding washer per microinverter. Torque the microinverter fasteners to the values listed below.
 - 1/4" mounting hardware – 45 in-lbs minimum
 - 5/16" mounting hardware – 80 in-lbs minimum

Compatible grounding washer part numbers are included in the Racking Compatibility Application Note. Installation guidelines are included in the Grounding Washer Application Note. Refer to both documents at: <http://www.enphaseenergy.com/support/downloads.cfm>

Step 3 – Install the AC Trunk Cabling

- a. Fasten the AC trunk cable to the racking system so that the tap cables align with the microinverter locations.
- b. Connect the first AC trunk cable to the AC interconnect cable.
- c. Connect the AC trunk cables, end to end, to create the desired branch circuit length.



NOTE: The AC and DC connectors of each microinverter have been evaluated and approved for use as the load break disconnect as required by the NEC.



WARNING: Do NOT exceed the maximum number of microinverters in an AC branch circuit as listed on page 21 of this manual. Each microinverter AC branch circuit must be protected by a 20A maximum breaker.

- d. Plug the AC drop connectors of the trunk cable to the connector of a D380.
- e. Fasten the drop cable to the microinverter chassis slot next to the AC connector.
- f. Install a protective end cap on the open AC connector of the last AC trunk cable on the AC branch circuit.



WARNING: Make sure protective end caps have been installed on all unused AC connectors. Unused AC microinverter wire harness connectors may be live when the system is energized by the utility system.



WARNING: Size the AC wire gauge to account for voltage drop. All components of system wiring must be considered, including internal voltage drop within the length of ETD cabling. Use the voltage drop charts at: <http://www.enphaseenergy.com/support/downloads.cfm> to select the correct wire size based on the distance from the beginning of the microinverter branch circuit to the breaker in the load center. NEC guidelines for voltage drop on feeder and branch circuit conductors will not be adequate for microinverter branch circuits that contain the maximum allowable microinverters. Refer also to our *Voltage Drop Calculations Application Note* at <http://www.enphaseenergy.com/support/downloads.cfm>.

Step 4 – Ground the System

If you are not using grounding washers to ground the microinverter chassis as described in step 2, follow the step below. Each Enphase Microinverter comes with a ground clip that can accommodate a 6-10 AWG conductor.

- a. Route a continuous GEC through each of the microinverters to the NEC approved AC grounding electrode. The racking and module could be grounded to this conductor using a crimp connection. An alternative method would be to connect the microinverter to the grounded racking using a grounding washer approved for the racking.



NOTE: The AC output neutral is not bonded to ground inside the microinverter.

Step 5 – Complete the Installation Map and Connect the PV Modules

The Enphase Installation Map is a diagrammatic representation of the physical location of each microinverter in your PV installation. The virtual array in Enlighten is created from the map you create. Use the blank map in the Appendix to record microinverter placement for the system, or provide your own layout if a larger or more intricate installation map is required.

Complete the Enphase Map

- a. Each Enphase Microinverter has a removable serial number label located on the mounting plate. Peel the removable serial number label from each Enphase Microinverter and affix it to the respective location on the Enphase installation map (see map on page 25). You can also download installation maps and examples from www.enphaseenergy.com/quickstart. Remember to keep a copy of the installation map for your records.

Alternative: Create Your Own Map

- a. Draw a top-down view of the array using the Array Map template (using either the grid on Side A or the freeform area on Side B). Make sure to leave enough room to place the serial number stickers.
- b. When installing the microinverters, remove the serial number labels located next to the DC input cables and place them in the correct order on your drawing of the system. Remember to keep a copy of the installation map for your records.

Connect the PV Modules



NOTE: Completely install all microinverters and all system inter-wiring connections prior to installing the PV modules.

- a. Mount the PV modules above the microinverters. Each microinverter comes with two sets of oppositely sexed multi-contact connectors.
- b. First connect the positive DC wire from the PV module to the negatively marked DC connector (male pin) of the microinverter. Then connect the negative DC wire from the PV module to the positively marked DC connector (female socket) of the microinverter. This process will need to be repeated for both A and B inputs of the microinverter. Repeat for all remaining PV modules using one D380 for two PV modules.

Step 6 – Build the Virtual Array

In this step, you will create the virtual array in Enlighten from the map you created in the last step. Once the virtual array is built, Enlighten displays a graphic representation of the PV system. It also shows detailed current and historical performance information. Please go to www.enphaseenergy.com for more information on the Enphase Enlighten web-based monitoring and analysis.

- a. Use Array Builder to create the virtual array in Enlighten.



NOTE: Go to <http://www.enphaseenergy.com/support/learningcenter.cfm> to view an Array Builder demo.

- b. If you do not already have an account, please go to www.enphaseenergy.com for more information on the Enphase Enlighten web-based monitoring and analysis.

Commissioning



WARNING: Connect the Enphase Microinverter to the electrical utility grid only after receiving prior approval from the utility company.



WARNING: Be aware that only qualified personnel must connect the Enphase Microinverter to the electrical utility grid.



WARNING: Ensure that all AC and DC wiring is correct. Ensure that none of the AC and DC wires are pinched or damaged. Ensure that all junction boxes are properly closed.



NOTE: The Status LED of each microinverter will blink green six times to indicate normal start-up operation **one minute after DC power is applied.**

To commission the Enphase Microinverter PV system:

1. Turn ON the AC disconnect or circuit breaker on each microinverter AC branch circuit.
2. Turn ON the main utility-grid AC circuit breaker. Your system will start producing power **after a five-minute wait time.**
3. The Enphase Microinverters will start to send performance data over the power lines to the Envoy. The time required for all the microinverters in the system to report to the Envoy will vary with the number of microinverters in the system. The first units should be detected within 15 minutes but the entire system could take hours to detect. Please refer to the *Envoy Installation and Operation Manual* for information on the Envoy.

Operating Instructions

The Enphase Microinverter is powered on when sufficient DC voltage from the module is applied. The status LED will blink green six times indicating proper start-up. The TwinPack Microinverter can be powered from either the A or B DC input and only requires a module to be connected to one of the inputs to operate. A single status LED reports for both the A and B DC inputs.



NOTE: In the event of a GFDI failure, the status LED will display continuous red after the fault occurs. This will persist when AC and DC power are cycled to the microinverter. Refer to page 17 for information on troubleshooting a GFDI condition.

You can also verify proper operation of the Enphase Microinverters via the Envoy. See the *Envoy Communications Gateway Installation and Operation Manual* for more information.

Troubleshooting

Adhere to all the safety measures described throughout this manual. Qualified personnel can use the following troubleshooting steps if the PV system does not operate correctly.



WARNING: Do not attempt to repair the Enphase Microinverter; it contains no user-serviceable parts. If it fails, please contact Enphase customer service to obtain an RMA number and start the replacement process.

Status LED Indications and Error Reporting

Startup LED Operation:

One minute after DC power is first applied to the microinverter, six short green blinks indicate a successful microinverter startup sequence.

Six short red blinks after DC power is first applied to the microinverter indicate a failure during microinverter startup.

Post-Startup LED Indications:

Flashing Green – Producing power and communicating with Envoy

Flashing Orange – Producing power and not communicating with Envoy

Flashing Red – Not producing power

GFDI Fault:

A solid red status LED when DC power has been cycled, indicates the microinverter has detected a ground fault (GFDI) error. The LED will remain red and the fault will continue to be reported by the Envoy until the error has been cleared.

The condition should clear with operator intervention, unless conditions causing the event have not been remedied or if the failure is permanent. Follow the instructions in the *Envoy Communications Gateway Installation and Operation Manual* to clear this condition. Or, for assistance, contact Enphase Energy customer support at 877-797-4743 or at support@enphaseenergy.com.

Other Faults:

All other faults are reported to the Envoy. Refer to the *Envoy Installation and Operation Manual* for a list of additional faults and troubleshooting procedures.



WARNING: Be aware that only qualified personnel should troubleshoot the PV array or the Enphase Microinverter.

Troubleshooting an Inoperable Microinverter

To troubleshoot an inoperable microinverter, follow the steps in the order shown:

1. Check the connection to the utility grid. Verify the utility voltage and frequency are within allowable ranges shown in the Technical Data section on page 20 of this manual. Verify utility power is present at the inverter in question by removing AC, then DC power. **Never disconnect the DC wires while the microinverter is producing power.** Re-connect the DC module connectors. After one minute, watch for six short LED blinks.
2. Check the AC branch circuit interconnection harness between all the microinverters. Verify that each inverter is energized by the utility grid as described in the previous step.
3. Make sure that any AC disconnects are functioning properly and are closed.
4. Verify the PV module DC voltage is within the allowable range shown in the Technical Data section on page 20 of this manual.
5. Check the DC connections between the microinverter and the PV module.
6. If the problem persists, please call customer support at Enphase Energy.



WARNING: Do not attempt to repair the Enphase Microinverter; it contains no user-serviceable parts. If troubleshooting methods fail, please return the microinverter to your distributor for maintenance.

Disconnecting a Microinverter from the PV Module

To ensure the microinverter is not disconnected from the PV modules under load, adhere to the following disconnection steps in the order shown:

1. Disconnect the AC by opening the branch circuit breaker.



WARNING: Never disconnect the DC wire connectors under load. Ensure that no current is flowing in the DC wires prior to disconnecting. An opaque covering may be used to cover the module prior to disconnecting the module.



WARNING: Always disconnect AC power before disconnecting the PV module wires from the Enphase Microinverter. The AC connector of the first microinverter in a branch circuit is suitable as a disconnecting means once the AC branch circuit breaker in the load center has been opened.



WARNING: The Enphase Microinverters are powered by DC power from the PV modules. Make sure you disconnect the DC connections and reconnect DC power to watch for the six short LED blinks one minute after DC is applied.

2. Disconnect the first AC connector in the branch circuit.
3. Cover the module with an opaque cover.

4. Using a DC current probe, verify there is no current flowing in the DC wires between the PV module and the microinverter.
5. Care should be taken when measuring DC currents, most clamp-on meters must be zeroed first and tend to drift with time.
6. Disconnect the PV module DC wire connectors from the microinverter.
7. Remove the microinverter from the PV array racking.

Installing a Replacement Microinverter

1. Attach the replacement microinverter to the PV module racking using hardware recommended by your module racking vendor. If you are using grounding washers (e.g. WEEB) to ground the chassis of the microinverter, the old grounding washer should be discarded, and a new grounding washer must be used when installing the replacement microinverter. Torque the microinverter fasteners to the values listed below.
 - 1/4" mounting hardware – 45 in-lbs minimum
 - 5/16" mounting hardware – 80 in-lbs minimum
2. If you are using a grounding electrode conductor to ground the microinverter chassis, attach the grounding electrode conductor to the microinverter ground clamp.
3. Connect the AC cable of the replacement microinverter and the neighboring microinverters to complete the branch circuit connections.
4. Energize the branch circuit breaker, and verify operation of the replacement microinverter by checking the indicator light.
5. Initiate a device scan at the Envoy. To do this, press and hold the Menu button on Envoy for two seconds to bring up the Envoy menu on the LCD window. When the LCD window displays "Enable Communication Check", release the Menu button.
6. Use Enlighten's Array Builder function to add the newly detected microinverter to the virtual array.



NOTE: To view an Array Builder demonstration, go to <http://www.enphaseenergy.com/support/learningcenter.cfm>.

Technical Data

Technical Considerations

The Enphase D380 Microinverters are designed to operate with most 60 and 72-cell PV modules. Be sure to verify the voltage and current specifications of your PV module match with those of the microinverter. For more information, refer to the Enphase website (<http://www.enphaseenergy.com/support/downloads.cfm>) for a list of compatible PV module racking systems and PV modules.



WARNING: You must match the DC operating voltage range of the PV module with the allowable input voltage range of the Enphase Microinverter.



WARNING: The maximum open circuit voltage of the PV module must not exceed the specified maximum input voltage of the Enphase Microinverter.

The output voltage and current of the PV module depends on the quantity, size and temperature of the PV cells, as well as the solar insolation on each cell. The highest PV module output voltage occurs when the temperature of the cells is the lowest and the module is at open circuit (not operating). The maximum short circuit current rating of the module must be equal to or less than the maximum input DC short circuit current rating of the microinverter. A list of compatible PV modules is maintained on the Enphase website (<http://www.enphaseenergy.com/support/downloads.cfm>).

Technical Specifications

The D380 Microinverters contain two independent DC inputs. The DC operating parameters below apply to both DC inputs A and B individually.

Enphase D380 TwinPack Microinverter Operating Parameters				
Topic	Unit	Min	Typical	Max
DC Operating Parameters				
MPPT voltage range	V	22		40
Maximum DC input voltage	V			56
Minimum / Maximum start voltage	V	28		54
Maximum DC input short circuit current	A			12
Maximum DC input current	A			10
Ground fault protection	mA			1000
Maximum input source backfeed current to input source	A			0

Enphase D380 TwinPack Microinverter Operating Parameters				
Topic	Unit	Min	Typical	Max
AC Operating Parameters				
Maximum AC output Power (-40 to 65 °C)	W	380		
Output power factor		0.95	0.99	1
Nominal AC output voltage range D380-72-2LL-S1x or D380-72-2LL-S1x-NA @240 Vac	Vrms	211	240	264
D380-72-2LL-S1x or D380-72-2LL-S1x-NA @ 208 Vac	Vrms	183	208	229
Extended AC output voltage range D380-72-2LL-S1x or D380-72-2LL-S1x-NA @ 240 Vac	Vrms	206	240	269
D380-72-2LL-S1x or D380-72-2LL-S1x-NA @ 208 Vac	Vrms	179	208	232
Maximum AC output current D380-72-2LL-S1x or D380-72-2LL-S1x-NA @ 240 Vac	A		1.6	1.8
D380-72-2LL-S1x or D380-72-2LL-S1x-NA@ 208 Vac	A		1.8	2.0
Nominal AC output frequency range	Hz	59.3	60	60.5
Extended AC output frequency range	Hz	59.2	60	60.6
Maximum AC output over current protection	A	20 A		
Maximum AC output fault current & duration	A _p /ms	47Apk over 3.51ms 2.18Arms over 3 cycles 2.16Arms over 5 cycles		
High AC Voltage trip limit accuracy	%	±2.5		
Low AC Voltage Trip limit accuracy	%	±4.0		
Frequency trip limit accuracy	Hz	±0.1		
Trip time accuracy	ms	±33		
Miscellaneous Operating Parameters				
Maximum inverters per 20 amp AC branch circuit				
D380-72-2LL-S1x or D380-72-2LL-S1x-NA @ 240 Vac		1		10
D380-72-2LL-S1x or D380-72-2LL-S1x-NA@ 208 Vac		1		15
Peak inverter efficiency	%			95.5
CEC weighted efficiency	%			95.0
Nominal MPP tracking efficiency	%			99.6
Total Harmonic Distortion	%		2.5	5

Enphase D380 TwinPack Microinverter Operating Parameters

Topic	Unit	Min	Typical	Max
Operating temperature range	°C	-40		65
Night Tare Loss	mW		50	
Storage temperature range	°C	-40		65

Features

Dimensions (approximate)	12.25" x 6" x 1.33 "
Weight	6.25 Lbs
Enclosure environmental rating	NEMA6
Cooling	Convective – no fan
AC cable rating	TC-ER, #12 AWG, Dry-rated to 90°C, UV-resistant, crush-resistant, direct burial
DC cable rating	USE-2, #10 AWG
Communication	Power line
GFDI	A GFI sensor is internal to the microinverter and meets UL 1741.
Standard warranty term	15 years
Compliance	UL 1741, IEEE 1547, FCC Part 15 Class B
Integrated AC Disconnect	The AC connector has been evaluated and approved for use as the load-break disconnect required by the NEC.
Integrated DC Disconnect	The DC connector has been evaluated and approved for use as the load-break disconnect required by the NEC.

Voltage and Frequency Limits for Utility Interaction

Condition	Simulated utility source		Maximum time (sec) (cycles) at 60 Hz before cessation of current to the simulated utility
	Voltage (V)	Frequency (Hz)	
A	$< 0.50 V_{\text{Typical}}$	Rated	0.16
B	$0.50 V_{\text{Typical}} \leq V < 0.88 V_{\text{Typical}}$	Rated	2
C	$1.10 V_{\text{Typical}} < V < 1.20 V_{\text{Typical}}$	Rated	1
D	$1.20 V_{\text{Typical}} \leq V$	Rated	0.16
E	Rated	$f > 60.5$	0.16
F	Rated	$f < (59.8 - 57.0)$	0.16 – 300
G	Rated	$f < 57.0$	0.16

Appendix

Limited Warranty

Enphase Energy Inc. ("**Enphase**") has developed a highly reliable microinverter that is designed to withstand normal operating conditions when used for its originally intended purpose in compliance with the Enphase User Manual supplied with the originally shipped system. The Enphase limited warranty ("**Limited Warranty**") covers defects in workmanship and materials of the Enphase Microinverter ("**Defective Product**") for a period of fifteen (15) years from the date of original purchase of such microinverter at point of sale to the originally-installed end user location (the "**Warranty Period**"). During the Warranty Period, the warranty is transferable to a different owner as long as the microinverter remains installed at the originally-installed end user location.

During the Warranty Period, Enphase will, at its option, repair or replace the Defective Product free of charge, provided that Enphase through inspection establishes the existence of a defect that is covered by the Limited Warranty. Enphase will, at its option, use new and/or reconditioned parts in repairing or replacing the Defective Product. Enphase reserves the right to use parts or products of original or improved design in the repair or replacement of Defective Product. If Enphase repairs or replaces a Defective Product, the Limited Warranty continues on the repaired or replacement product for the remainder of the original Warranty Period or ninety (90) days from the date of Enphase's return shipment of the repaired or replacement product, whichever is later.

The Limited Warranty covers both parts and labor necessary to repair the Defective Product, but does not include labor costs related to un-installing the Defective Product or re-installing the repaired or replacement product. The Limited Warranty also covers the costs of shipping repaired or replacement product from Enphase, via a non-expedited freight carrier selected by Enphase, to locations within the United States (including Alaska and Hawaii) and Canada, but not to other locations outside the United States or Canada. The Limited Warranty does not cover, and Enphase will not be responsible for, shipping damage or damage caused by mishandling by the freight carrier and any such damage is the responsibility of the freight carrier.

To obtain repair or replacement service under this Limited Warranty, the customer must comply with the following policy and procedure:

- All Defective Product must be returned with a Return Merchandise Authorization Number (RMA) which customer must request from Enphase. Before requesting the RMA, however, the customer should contact an Enphase technical support representative to evaluate and troubleshoot the problem while the Enphase Microinverter is in the field, since many problems can be solved in the field.
- If in-field troubleshooting does not solve the problem, Customer may request the RMA number, which request must include the following information:
 - Proof-of-purchase of the Defective Product in the form of (1) the dated purchase receipt from the original purchase of the product at point of sale to the end user, or (2) the dated dealer invoice or purchase receipt showing original equipment manufacturer (OEM) status, or (3) the dated invoice or purchase receipt showing the product exchanged under warranty.

- Model number of the Defective Product
- Serial number of the Defective Product
- Detailed description of the defect
- Shipping address for return of the repaired or replacement product
- All Defective Product authorized for return must be returned in the original shipping container or other packaging that is equally protective of the product
- The returned Defective Product must not have been disassembled or modified without the prior written authorization of Enphase

Enphase Microinverters are designed to withstand normal operating conditions and typical wear and tear when used for their original intent and in compliance with the installation and operating instructions supplied with the original equipment. The Limited Warranty does not apply to, and Enphase will not be responsible for, any defect in or damage to any Enphase Microinverter: (1) that has been misused, neglected, tampered with, altered, or otherwise damaged, either internally or externally; (2) that has been improperly installed, operated, handled or used, including use under conditions for which the product was not designed, use in an unsuitable environment, or use in a manner contrary to the Enphase User Manual or applicable laws or regulations; (3) that has been subjected to fire, water, generalized corrosion, biological infestations, acts of God, or input voltage that creates operating conditions beyond the maximum or minimum limits listed in the Enphase Microinverter specifications, including high input voltage from generators or lightning strikes; (4) that has been subjected to incidental or consequential damage caused by defects of other components of the solar system; or (5) if the original identification markings (including trademark or serial number) of such microinverter have been defaced, altered, or removed. The Limited Warranty does not cover costs related to the removal, installation or troubleshooting of the customer's electrical systems. The Limited Warranty does not extend beyond the original cost of the Enphase Microinverter.

THE LIMITED WARRANTY IS THE SOLE AND EXCLUSIVE WARRANTY GIVEN BY ENPHASE AND, WHERE PERMITTED BY LAW, IS MADE EXPRESSLY IN LIEU OF ALL OTHER WARRANTIES, EXPRESS OR IMPLIED, STATUTORY OR OTHERWISE, INCLUDING, WITHOUT LIMITATION, WARRANTIES OF TITLE, QUALITY, MERCHANTABILITY, FITNESS FOR A PARTICULAR PURPOSE OR NON-INFRINGEMENT OR WARRANTIES AS TO THE ACCURACY, SUFFICIENCY OR SUITABILITY OF ANY TECHNICAL OR OTHER INFORMATION PROVIDED IN MANUALS OR OTHER DOCUMENTATION. IN NO EVENT WILL ENPHASE BE LIABLE FOR ANY SPECIAL, DIRECT, INDIRECT, INCIDENTAL OR CONSEQUENTIAL DAMAGES, LOSSES, COSTS OR EXPENSES HOWEVER ARISING, WHETHER IN CONTRACT OR TORT, INCLUDING WITHOUT LIMITATION ANY ECONOMIC LOSSES OF ANY KIND, ANY LOSS OR DAMAGE TO PROPERTY, OR ANY PERSONAL INJURY.

To the extent any implied warranties are required under applicable law to apply to the Enphase Microinverter, such implied warranties shall be limited in duration to the Warranty Period, to the extent permitted by applicable law. Some states and provinces do not allow limitations or exclusions on implied warranties or on the duration of an implied warranty or on the limitation or exclusion of incidental or consequential damages, so the above limitation(s) or exclusion(s) may not apply. This Limited Warranty gives the customer specific legal rights, and the customer may have other rights that may vary from state to state or province to province.




Enphase Installation Map

Panel Group: Azimuth: Tilt: sheet ___ of ___		Customer information:			Installer information:			N S E W (circle one)
1	2	3	4	5	6	7		
A								
B								
C								
D								
E								
F								
G								
H								
J								
K								
L								
M								
Scan completed map and upload to the Activation page online at www.enphaseenergy.com . Use this map to build the virtual array in Enlighten Array Builder.		Envoy Serial Label			 <small>ENPHASEENERGY.COM</small>			<small>DOCUMENT NUMBER</small> 140-00003 <small>REVISION</small> 03




Sample Wiring Diagram – D380, 240 Vac





Sample Wiring Diagram – D380, 208 Vac





Enphase Energy Inc.
201 1st Street
Petaluma, CA 94952
Phone: 707-763-4784
TOLL FREE: 877-797-4743
Fax: 707-763-0784
www.enphaseenergy.com
info@enphaseenergy.com